

# Owners Manual



### READ AND SAVE THESE INSTRUCTIONS

#### WARNING:

TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR INJURY TO PERSONS, OBSERVE FOLLOWING:

- 1. Use this unit only in manner intended by the manufacturer. If you have questions, contact the manufacturer at the address or telephone number listed in warranty.
- Before servicing or cleaning unit, or Installing a light kit, switch power off at service panel and look service panel to prevent power from being switched on accidentally. When the service disconnecting means cannot be locked, securely fasten a prominent warning device, such as a tag, to the service panel.
- 3. Installation work and electrical wiring must be done by a qualified person(s) in accordance with all applicable codes and standards, including fire- rated construction codes and standards.
- 4. If the fan will be mounted to ceiling box, the box and its support must be able to support the moving weight of the fan (at least 40 lbs.) The box must not twist or work loose.


#### WARNING:


TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR PERSONAL INJURY, MOUNT TO OUTLET BOX MARKED ACCEPTABLE FOR FAN SUPPORT AND USE MOUNTING SCREWS PROVIDED WITH OUTLET BOX.


- 5. If the fan will be mounted to a celling joist, the joist must be able to support the moving weight of the fan (at least 40 lbs.)
- 6. When cutting or drilling into wall or ceiling, do not damage electrical wiring and other hidden utilities.
- 7. This unit must be grounded.
- 8. After installation is complete, make sure that all connections are secure to prevent the fan from falling. Make sure all wire connections are secure, and that there are no exposed conductor strands.
- 9. WARNING: TO REDUCE THE RISK OF PERSONAL INJURY, DO NOT BEND THE BLADE BRACKETS WHEN INSTALLING THE BRACKETS, BALANCING THE BLADES, OR CLEANING THE FAN. DO NOT INSERT FOREIGN OBJECTS IN BETWEEN ROTATING FAN BLADES.
- 10.Make sure that your Installation will not allow the fan to come into contact with any adjacent obstacles such as doors, hanging lamps, etc.
- 11. If you are installing more than one celling fan, do not mix the blade sets.
- 12. The fan must be mounted with at least 7 feet of clearance between fan blades and floor.
- 13. This fan is sultable for WET or DAMP locations depending on model, including covered porches, covered decks, or covered gazebos.
  - WARNING: THE USE OF ANY SPEED CONTROL NOT SPECIFICALLY APPROVED FOR THIS FAN COULD RESULT IN FIRE, ELECTRICAL SHOCK, OR PERSONAL INJURY.



Dan's Fan City, Inc. Gulf Coast Fans, Inc. 300 Dunbar Avenue Oldsmar, FL 34677-0106 1.Unpack and inspect fan carefully to be certain all contents are









mounting bracket from box.


## Hanging the fan





Carefully lift fan assembly onto mounting bracket.
Rotate fan so that the notch on the ball engages the ridge in the mounting bracket.

## 7. Making wire connection




Follow diagram above.

Make sure that all exposed wires are secured inside wire nuts.


NOTE:

Wires from house may vary in color and may not include ground wire (Green). After wiring is complete, Gently push wires into junction box with nuts pointing upward.




Secure with twist - lock wire connectors. (Included)


## 8. Canopy Installation




Before pushing up the canopy, make sure the gasket on top of ball is properly inserted for effective water-proofing.




Push up the canopy till two center holes on each side are engaged with two spring ridges on two sides of mounting bracket.





11. Connect the Pull Chain knob to speed chain



12. Turn the power back on at the breaker box. Your fan is read for operation.